

Wood's®

SS-7002 Digital hygrotermometer

Wood's digitala hygrotermometer SS-7002 används för att mäta temperatur och fuktighetsnivå i ett utrymme. Den 2,5 m långa sladden gör det enkelt att kontrollera temperatur och fukt, även i svårtillgängliga utrymmen. Sladden leds in i utrymmet och själva enheten placeras i ett rum i dess närhet. Med hjälp av larmet vet du när temperatur eller fuktighetsnivå över- eller understiger dina tillåtna nivåer.

Hygrotermometers visar aktuell temperatur eller fuktighetsnivå samt de högsta och lägsta värden som uppmätts sedan enheten sist nollställdes.



Ställ in larm för fuktighetsnivå

1. Välj visningsläget fuktighet genom att trycka på **MODE**.
2. Håll knappen **SET** nertryckt tills displayen börjar blinka. Nu visas några streck och texten **HI%** som representerar det högsta tillåtna värdet.
3. Tryck på **MODE** så att strecken ändras till siffror.
4. Ställ in det högsta tillåtna fuktighetsnivån genom att trycka upprepade gånger på **CLEAR** och tryck sedan på **SET** för att bekräfta ditt val.
5. Återigen blinkar några streck och texten **LO%** visas. Upprepa steg 2-3 för att ställa in larm för lägsta tillåtna värde.

Ställ in larm för temperaturnivå

1. Välj visningsläget temperatur genom att trycka på **MODE**.
2. Håll knappen **SET** nertryckt tills displayen börjar blinka. Nu visas några streck och texten **HI°C** som representerar det högsta tillåtna värdet.
3. Tryck på **MODE** så att strecken ändras till siffror.
4. Ställ in den högsta tillåtna temperaturen genom att trycka upprepade gånger på **CLEAR** och tryck sedan på **SET** för att bekräfta ditt val.
5. Återigen blinkar några streck och texten **LO°C** visas. Upprepa steg 2-3 för att ställa in larm för lägsta tillåtna värde.

Konsumentkontakt:

TES Scandinavia AB
Maskingatan 2-4, 441 39 Alingsås
www.woods.se
info@woods.se, +46(0)317613610

Stänga av larmfunktionen

Hygrotermometern larmar tills det inställda värdet ändras. Håll ner knappen **SET** tills larmet tystnar och ställ sedan in nya larmvärden.

Nollställa värdena MAX och MIN

1. Välj visningsläget temperatur eller fuktighetsnivå.
2. Tryck på knappen **CLEAR** för att nollställa.

Som tecken på att värdena har nollställts kommer ett antal streck att visas i displayen innan den aktuella temperaturen och fuktighetsnivån visas.

Visning i Celsius eller Fahrenheit.

Välj visningsläge med knappen på baksidan av hygrometern.

Byta batterier

Dra batteriluckan på baksidan nedåt tills den lossnar. Sätt i två st AAA-batterier enligt symbolerna i batterifacket.

Specifikationer

Mätområde fuktighet	10% till 99%
Felmarginal	± 5%
Mätområde temperatur	-50°C till +70°C
Felmarginal	± 1°C

Wood's®

SS-7002 Digital hygro-thermometer

Wood's digital hygro-thermometer SS-7002 is used to measure temperature and humidity in a room. The 2,5 m long cord makes it easy to monitor temperature and humidity, even in rooms that are inaccessible. The cord is lead to the space and the unit placed in a room in its proximity. By using the alarm function you'll know when temperature and humidity exceeds your set values.

The display shows current temperature and humidity as well as the highest and lowest values measured since the unit was last reset.



Set alarm for humidity

1. Select humidity by pressing the **MODE** button.
2. Press and hold the **SET** button until the display starts flashing. A few dashes are shown in the display along with the text **HI%**, representing the highest allowed value.
3. Press **MODE** again to change the dashes to numbers.
4. Set the highest allowed humidity level by repeatedly pressing **CLEAR**. Press **SET** to confirm.
5. A few dashes are again shown in the display along with the text **LO%**. Repeat steps 2-3 to set the alarm for the lowest allowed value.

Set alarm for temperature

1. Select temperature by pressing the **MODE** button.
2. Press and hold the **SET** button until the display starts flashing. A few dashes are shown in the display along with the text **HI°C**, representing the highest allowed value.
3. Press **MODE** again to change the dashes to numbers.
4. Set the highest allowed humidity level by repeatedly pressing **CLEAR**. Press **SET** to confirm.
5. A few dashes are again shown in the display along with the text **LO°C**. Repeat steps 2-3 to set the alarm for the lowest allowed value.

Shutting of the alarm

The hygro-thermometer will alarm until the set value is changed. Press and hold the **SET** button until the alarm stops and then set new values.

Reset MAX and MIN values

1. Select humidity or temperature.
2. Press the **CLEAR** button to reset.

When reset, a few dashes are shown in the display before new values are shown.

Select Celsius or Fahrenheit.

Press the button on the back of the unit to switch between Celsius and Fahrenheit.

Replace the batteries

Slide the battery latch downwards until it comes off. Insert two AAA- batteries according to the markings.

Specifications

Range humidity	10% till 99%
Accuracy	± 5%
Range temperature	-50°C till +70°C
Accuracy	± 1°C

Contact:

TES Scandinavia AB
Maskingatan 2-4. SE 441 39 Alingsås
www.woodsdehums.com
info@woods.se, +46(0)317613610